

Canon® PC-310/330-E16-E31



Oasis Imaging Products, Inc. Technical Support: (800) 322- 8992 ext 110

Reference Information:

OEM PN: F41-8802-710

OEM Yield: 1600 @ 5% coverage

Recommended Tools

Small flathead screwdriver

Needle nose pliers

99% Isopropyl Alcohol

Approximate Remanufacturing

Time: 20 min.

Instructions:

1. Use a small screwdriver to unlatch the eight plastic clips on the toner cartridge (six clips on the underside, and one clip on each end Figs. 1,2).
2. Carefully lift the lower half of the cartridge to separate the halves (be careful not to snap off any of the clips). Any toner remaining in the cartridge will spill.
3. Vacuum any toner spills and all remaining toner in cartridge.
4. Remove the primary corona roller (PCR) and clean with Anakenesis® PCR cleaner (Fig. 3). Use compressed air or a vacuum to clean out the cartridge half.
5. Pry the steel drum axle as far out as possible from the cartridge with a small screwdriver (Fig. 4).
6. Remove the steel drum axle with a pair of needle nose pliers (Fig. 5). Handle the drum by the white gears to remove it from the cartridge.
7. Remove the two screws holding the wiperblade in place.
8. Clean and store drum in a dark place.
9. Vacuum out the wastebin and hopper.
10. Clean the black conductive clip that holds the charge roller in place with a cotton swab and 99% IPA (see Fig. 3).
11. Install the PCR.
12. Lubricate the drum and wiperblade with padding powder.
13. Install wiperblade, then the OPC drum.
14. Secure the cartridge in an upright position and fill the hopper with toner. Install seal if necessary.
15. Keeping the cartridge upright, carefully join the two halves together, making sure all clips are latched. **NOTE:** In the event that any clips should be broken, optional screw holes are included on the cartridge halves in order to insure a proper seal (Fig. 1).




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5

Oasis and You ... Succeeding Together!



New Hampshire
(603) 880-3991
(800) 322-8992
Fax: (603) 598-4277

Tennessee
(800) 322-8992
Fax: (901) 366-9756

Texas
(800) 322-8992
Fax: (972) 692-6976

Canada
(800) 322-8992
Fax: (972) 692-6976

South America
(800) 322-8992
International:
(603) 880-1552
Fax: (603) 386-7575

Illinois
(800) 322-8992
Fax: (972) 692-6976

California
(800) 322-8992
Fax: ((714) 908-7788

North Carolina
(800) 322-8992
Fax: (603) 386-7575

Europe
Netherlands
011-31-24-388-2233
Fax: 011-31-24-355-7373

© 1998 Oasis Imaging Products, Inc. Any attempt to reproduce any part of these instructions without the written consent of Oasis Imaging Products, Inc. may result in legal action. All registered trademarks are the property of their respective owners.